

Product name:

Rockcote MultiStop Finishing Compound

Description:

It is a plaster for use over general masonry substrates for finishing. It is often used to patch tilt panels. This plaster can be sanded to achieve the desired finish. Often 2 coats is used to achieve a very flat finish.

Typical Use:

Finishing render to achieve a smooth finish..

Expectation:

MultiStop Finishing Compound is used over all substrates to give an attractive durable surface ready for painting.

Limitations:

Two coats are required. Not suitable for application over wood based substrates. It requires painting to achieve weathertightness.

Technical Data:

Mix ratio:	15kg plaster requires approx. 4L of water
Coverage:	1mm thick approx. 15m ²
Substrates:	all prepared base coats of plaster
Abrasive strength:	Excellent
Adhesion:	Excellent
Vapour Permeability:	No vapour barrier formed
VOC:	N/A
Colour:	grey
Packaging:	15kg bags
Clean up:	Water while product is wet
Use by:	12months from date of manufacture
Storage:	Cool, dry place, off the ground
Application Temperature:	+ 5 °C to + 30 °C
Usual No Coats:	1
Drying Time:	24 hours
Touch Dry:	4 hours
Dry to Recoat:	12 hours
Film Build:	Approximately 1mm dry film build per coat
Thinning:	N/A

Mean Vapour flow rate:	104.31g/m ² d (ASTM E96/E96M-13 Water Method)
Mean Resistance:	1.06MNs/g (ASTM E96/E96M-13 Water Method)
Fire Group Classification:	1-S (Test in accordance with ISO 5660:2002)

Surface Preparation:

Ensure the surface is clean, sound, dry and free from dust, dirt, grease, mould and lichen. Painted surfaces should have a slurry coat applied.

Application:

Plaster is applied not greater than 1mm with a steel trowel to a flat finish. A range of finishes can be achieved using sponges or steel trowels. Apply plaster only when the temperature is between 5°C and 30°C and will be in that range for the 24 hours period following application.

Curing:

MultiStop Finishing Compound should be protected from hot drying winds and direct sunlight for the first 16 hours. Protect newly applied plaster from rain and water run off for the first 24 hours.

Clean up:

Wash equipment and spills as soon as possible with water.

Environmental and Safety

Ensure washing water does not enter waterways. Wet waste should be disposed of in empty bags, once dry dispose of in trade waste. The powder is an irritant and appropriate PPE dust masks are advised when handling. The wet compound is Alkaline and prolonged skin contact should be avoided. Wear rubber gloves, dust masks and safety glasses when handling products.

Material Safety Data Sheets are available upon request or access directly from <https://reseneconstruction.co.nz/technical-library/safety-data-sheets/>